

1 из 9







Windage and Elevation Adjustment Lock Screw

Battery Compartment

Low Mount Base with Lock Screw

Windage Adjustment Dial